

Field Install Procedure for SAFESOCK

1. Carefully slide the shrink tube over cable jacket.



2. Carefully slide the Techflex wrap over fan-out and under shrink tube - gently without bending / compromising the fiber cables.



3. Use heat gun to permanently affix cable jacket and the Techflex sock together at the cable fan-out

**** DO NOT pull your cable using this component. Please use extreme caution during install of SAFESOCK-1 as fibers are extremely fragile ****

Pulling / installing fiber optic cables into conduit / walls / plenum area should only be done by a professional utilizing approved pulling solutions and tools.

